



# Spray Dryer Process Air Permit

---

Hercules Research Center – 500 Hercules Road



Public Hearing  
December 8, 2016



# Wilmington Research Center Campus

Location of  
Spray Dryer  
Process



500 Hercules Road, Wilmington, Delaware 19808



Location of  
Spray Dryer  
Process



# Overview

---

- Seeking to permit pilot and lab scale R&D operation located in center of active 50 acre campus with 400 employees. Primarily weekday operation; limited after hours work.
- Hercules remains a subsidiary of Ashland and operates facility for Ashland
- Administrative and Research & Development (R&D) headquarters for Ashland
- Creates samples by replicating the way customers would use Ashland's products on smaller scale

# Proposed Operational Permit

---


- Spray dryers installed and operated pursuant to construction permits issued in April 2014
- Primary method of emissions reduction is activated carbon beds in canisters, which adsorb the pollutants

# Equipment Description

---

- Spray Dryers (3)
  - Makes dry powder by blowing hot gas (air or nitrogen) to evaporate liquid containing active ingredient, Ashland product and solvent
  - Powder collected in cyclone; solvent vapors from dryer collected in carbon bed
  - Condensed solvent is collected and disposed of as waste
- Fluid bed dryer (1) also creates powder from liquid containing active ingredient, Ashland product and solvent
- Carbon adsorption system (1) is a two carbon canister system that adsorbs solvent vapors from dryers for emissions reduction
  - The first carbon bed has a 90% efficiency
  - The second carbon bed provides additional reduction

# Pharmaceutical Spray Dryer



Closed loop configuration


Typical batch:

Run time = 4 hours

Sample size (solid) = 2 kg (4 lb)

Solvent used = 8 kg (18 lb or ~2.25 gal)

# Micro Spray Dryer



Once-through configuration

Typical batch:

Run time = 0.5 hours


Sample size (solid) = 0.02 kg (0.04 lb)

Solvent used = 0.38 kg (0.8 lb or ~13 oz)

Room height = 10 feet



# Fluid Bed Dryer



Process Flow Diagram

Typical batch:

Run time = 2 hours

Sample size (solid) = 0.2 kg (0.4 lb)

Solvent used = 1.8 kg (4 lb or ~0.5 gal)

# Carbon Adsorption System

---






Two 2,000 lb Activated Carbon Bed Canisters Operated in Series

# Potential Solvents Used



Solvent	Type
Ethanol	VOC
Isopropyl Alcohol	VOC
Ethyl Acetate	VOC
Tetrahydrofuran	VOC
Methanol	VOC-HAP
Methylene Chloride	HAP
Acetone	Non-VOC Non-HAP

# Potential Solvents Used


Solvent	Common Uses	Readily Available At	
Ethanol (Grain Alcohol)	<ul style="list-style-type: none"> <li>Beer, wine, alcohol</li> <li>Clean burning fuel for portable stoves</li> <li>Fuel and gasoline additive (Gasohol)</li> <li>Disinfectant</li> <li>Preservative for biological specimens</li> </ul> <p>Used in:</p> <ul style="list-style-type: none"> <li>Varnishes and perfumes</li> <li>Prep for essences and flavorings</li> <li>Medicines/drugs</li> </ul>	<ul style="list-style-type: none"> <li>Local liquor store (100 Proof = 50% Ethanol / 50% water plus some flavor; 150 Proof = 75% Ethanol / approx 25% water plus some flavor)</li> <li>Any hardware store such as Home Depot, Lowes, etc. as denatured alcohol in 1 quart cans</li> </ul>	  




# Potential Solvents Used

Solvent	Common Uses	Readily Available At	
Methylene Chloride	<ul style="list-style-type: none"> <li>• Paint stripper and a degreaser</li> <li>• Decaffeinates coffee and tea</li> <li>• Prepares extracts of hops and other flavorings</li> <li>• Aerosol spray propellant</li> <li>• Blowing agent for polyurethane foams</li> </ul>	<ul style="list-style-type: none"> <li>• Any hardware store such as Home Depot, Lowes, etc.</li> </ul> <p>(Note: Kleen Strip Stripper is about 80% Methylene Chloride, 20% Methanol)</p>	 

# Potential Solvents Used

Solvent	Common Uses	Readily Available At	
Isopropanol (IPA)	<ul style="list-style-type: none"> <li>• Rubbing Alcohol</li> <li>• Antiseptic, disinfectant</li> <li>• Toilet bowl and window cleaner</li> <li>• Swimmers Ear</li> </ul> <p>Widely used as:</p> <ul style="list-style-type: none"> <li>• Solvent and cleaning fluid, especially for dissolving oils</li> </ul>	<ul style="list-style-type: none"> <li>• Any drug store as either 70% or 90% IPA/water up to 99% IPA/water</li> <li>• Any home supply store as window cleaner</li> </ul>	

# Potential Solvents Used



Solvent	Common Uses	Readily Available At	
Methanol (Wood Alcohol)	<ul style="list-style-type: none"> <li>Windshield wiper fluid antifreeze</li> <li>Denaturant in denatured alcohol</li> <li>Clean burning fuel for portable stoves</li> <li>Biodiesel fuel production</li> </ul>	<ul style="list-style-type: none"> <li>Any hardware store such as Home Depot, Lowes, etc.</li> </ul>	

# Potential Solvents Used

Solvent	Common Uses	Readily Available At	
Acetone	<ul style="list-style-type: none"> <li>Nail polish remover</li> <li>Component in Superglue</li> </ul>	<ul style="list-style-type: none"> <li>Any drug store as nail polish remover</li> <li>Any hardware store such as Home Depot, Lowes, etc.</li> </ul>	  



# Potential Solvents Used

Solvent	Common Uses	Readily Available At	
Ethyl Acetate	<ul style="list-style-type: none"> <li>Glues</li> <li>Nail polish removers</li> <li>Decaffeinates coffee and tea</li> </ul>	<ul style="list-style-type: none"> <li>Any hobby store</li> </ul>	
Tetrahydrofuran (THF)	<ul style="list-style-type: none"> <li>Industrial solvent for polyvinyl chloride (PVC)</li> <li>Used in varnishes</li> </ul>	<ul style="list-style-type: none"> <li>Any hardware store such as Home Depot, Lowes, etc.</li> </ul> <p>(Note: Oatey PVC Cement contains 10 - 25% THF plus some Acetone)</p>	

# Safety

---

- Nitrogen used for flammable solvents
  - System kept under positive nitrogen pressure
- Interlock system
  - Temp/press/flow process parameters are monitored/interlocked
  - Won't operate unless condenser is working and system is airtight
  - Two oxygen sensors (primary and back-up) to shutdown system if air enters system
- Spill control and management
- Carbon bed redundancy
- Particle collection (baghouse and HEPA filter)

# Maintenance

---

- Per batch cleaning
- Carbon Beds
  - Replace when solvent vapors introduced to system is 85% of carbon bed capacity
  - Change out primary bed and move secondary bed to primary
- Leak test when operating and other maintenance as necessary
- Solvent waste is collected in drums and periodically disposed offsite through Ashland approved and state licensed vendors

# Monitoring


---

- Emission estimate
  - Track (via log) how much solvent is being used
  - Use an agency-approved material balance calculation that assumes that all solvents that are not condensed are sent to the carbon bed
- Leak test



---

THANK YOU



Ashland<sup>TM</sup>  
always solving

# Back-up Slides

---

# Wilmington Campus

---

Operations include:

- Primarily R&D activities
  - Molecular Science
  - Process Research
  - Measurement Science (Analytical & Materials)
  - Pharmaceutical and Nutrition
  - Industrial Specialties (includes Energy)
- Office/Administrative & Facility Services
- Aquarius – small scale Pharma production
- Solenis R&D for water technologies





# Our Markets and Applications

## Consumer Specialties

### Pharmaceutical

Oral solid & oral  
liquid dosage  
forms

Film coatings

Solubilization  
enhancement

Pharmaceutical  
services

### Nutrition

Food & beverage  
ingredients

Beer & wine  
stabilizers

Agriculture

## Industrial Specialties

### Coatings

Paint and coatings

Waterborne  
architectural &  
industrial coatings

Emulsion  
polymerization

### Construction

Dry mortar

Gypsum plasters

Joint compounds

Renders

Tile adhesives

Exterior insulation  
finishing systems

### Adhesives

Structural  
assembly

Flexible  
packaging and  
converting

Pressure-  
sensitive  
adhesives

Labels

### Energy

Drilling fluids

Cement slurries

Completion/  
workover fluids

Production &  
fracturing fluids

Kinetic inhibitors

Fluidized polymer  
suspensions

Gel pigs