



Geotextile Dewatering Bag



Plan



Aggregate underlayment if placed on soil surface

Profile

NOTE: Pre-manufactured products installed in accordance with manufacturer's recommendations may be used as an equivalent substitute with Departmental approval.

Source:

Adapted from
ACF Products, Inc.

Symbol:




Detail No.

DE-ESC-3.2.1.2

Sheet 1 of 2

Effective FEB 2019



Standard Detail & Specifications

Geotextile Dewatering Bag

Construction Notes:

1. The dewatering bag should be placed so the incoming water flows into and through the bag, and then flow off the site without creating more erosion. The neck should be tied off tightly to stop the water from flowing out of the bag without going through the walls. The dewatering bag should be placed on a gravel bed to allow water to flow in all directions.
2. The dewatering bag is considered full and should be disposed when it is impractical for the bag to filter the sediment out at a reasonable flow rate. At this point, it should be replaced with a new bag.
3. Disposal may be accomplished as directed by the construction reviewer. If the site allows, the bag may be buried on site and seeded, visible fabric removed and seeded or removed from site to a proper disposal area.

Materials:

1. The geotextile fabric shall be a Type GD-IV.
2. The dewatering bag shall be sewn with a double needle machine using high strength thread. All structural seams will be sewn with high strength, double stitched "J" type. Seam strength test will have the following minimum average roll values:

<u>Type</u>	<u>TEST METHOD</u>	<u>TEST RESULT</u>
Heavy duty	ASTM D-4884	100 lb / in

3. The dewatering bag shall have an opening large enough to accommodate a four (4) inch discharge hose with attached strap to tie off the hose to prevent the pumped water from escaping from the bag without being filtered.

Source:

Adapted from
ACF Products, Inc.

Symbol:



Detail No.

DE-ESC-3.2.1.2

Sheet 2 of 2

Effective FEB 2019