


## Stabilization Matting - Slope



Note: Use manufacturer's recommendations for stapling patterns for slope installations.

### Perspective

### Construction Notes:

1. Prepare soil before installing matting, including application of lime, fertilizer, and seed.
2. Begin at the top of the slope by anchoring the mat in a 6" deep X 6" wide trench. Backfill and compact trench after stapling.
3. Roll the mats (A) down or (B) horizontally across the slope.
4. The edges of parallel mats must be stapled with approx. 2" overlap.
5. When mats must be spliced down the slope, place mats end over end (shingle style) with approx. 4" overlap. Staple through overlapped area, approx. 12" apart.

Source:

Adapted from  
North American Green, Inc.

Symbol:




Detail No.


**DE-ESC-3.4.6.1**

Sheet 1 of 2


Effective FEB 2019




# Standard Detail & Specifications Stabilization Matting - Slope




0.7 Staples per Sq. Yd.




1.2 Staples per Sq. Yd.



1.75 Staples per Sq. Yd.



3.5 Staples per Sq. Yd.



3.75 Staples per Sq. Yd.

NOTE: These patterns are provided for general guidance only. They shall not be used as a substitute for manufacturer's recommendations.

## Stapling Patterns

Source:

Adapted from  
North American Green, Inc.

Symbol:



Detail No.

**DE-ESC-3.4.6.1**

Sheet 2 of 2

Effective FEB 2019